

Keep this
manual onboard!



User Manual

Including Installation Guide for Thruster
Monitoring Unit, TMU-1



SLEIPNER GROUP

P.O. Box 519

N-1612 Fredrikstad

Norway

www.sleipnergroun.com

DOCUMENT ID: 6995

REVISION: 4

DATE: 2024

LANGUAGE: EN



To download your language go to www.sleipnergroun.com

Contents

User Manual

Product Description	3
Layout & Functions	3
TMU-1 Technical Specifications	3
TMU-1 Configuration	4
S-Link Fault Codes	6
TMU-1 Fault Codes	6

Installation Manual

Responsibility of the Installer	7
TMU-1 Installation.....	8
S-Link System Description	9

Service and Support	10
----------------------------------	-----------

Product Spare Parts and Additional Resources.....	10
----------------------------------------------------------	-----------

Warranty Statement.....	10
--------------------------------	-----------

Patents.....	10
---------------------	-----------

CE Declaration of Conformity	11
-------------------------------------------	-----------

UK Declaration of Conformity	12
-------------------------------------------	-----------



Sleipner Motor AS
P.O. Box 519, Arne Svendsensgt. 6-8
N-1612 Fredrikstad, Norway


MC_0451

The Thruster Monitoring Unit (TMU-1) makes RPM of the thruster motor and gearleg low oil level alarm available on the S-Link bus. This requires a thruster motor with RPM sensor installed and Sleipner Oil tank kit supporting TMU-1.

Different TMU-1 product variants are available for interfacing motors with different RPM sensors. Both product variants are delivered with Oil Level Sensor Cable and RPM Sensor Cable.

Product	Oil Level Sensor Cable	RPM Sensor Cable	Comment
TMU-1-SAC	Cable length 5m	Cable length 5m M23 connector	For AC thrusters
TMU-1-SH	Cable length 5m	Cable length 5m Deutsch DT connector	For hydraulic motor

Layout & Functions



MG_0491

TMU-1 Technical Specification

Parameter	Specification		
Supply Voltage	Min 9VDC	Typical 12V/24V	Max 31VDC
Rated max input power	< 1W		
Operating temperature	-20°C to +70°C		
IP rating	IP66		
Weight	150g		
Size	121x96x43mm (WxLxH)		

The following parameters can be configured for TMU-1:

- Location
- Oil Level Sensor
- Speed Sensor
- Pulse Per Revolution

Location

TMU-1 can report data from 4 thruster locations.

Location	Description
Bow	Represents bow thruster or bow thruster on port side if two bow thrusters are installed.
Stern	Represent stern thruster or stern thruster on port side if two stern thrusters are installed.
Bow Starboard	Represents bow thruster on starboard side.
Stern Starboard	Represents stern thruster on starboard side.

Location should be configured to match the physical location of the thruster which the TMU-1 is connected to.

Default value for Location is Bow.

Oil Level Sensor

Some thrusters have the option of connecting an external oil tank to the gear leg. To monitor the oil level in the gear leg an oil tank with a level switch could be used. The level switch is normally closed and would open if the oil level in the tank goes beyond a certain level. To monitor the oil level and generate a low-level alarm the switch must be connected to the TMU-1. This parameter is used to disable or enable monitoring of the oil tank level switch.

Oil Level Sensor	Description
Enable	The TMU-1 monitors if the switch is closed or open and generates an alarm if the switch is open.
Disable	The TMU-1 does not monitor if the switch is closed or open. No alarm based on Oil Level Switch status is generated.

Default value for Oil Level Sensor is Enable.

Speed Sensor

This parameter is used to disable or enable RPM measurement.

Speed Sensor	Description
Enable	Measured RPM is reported on the S-Link bus.
Disable	RPM measurement is not reported on the S-Link bus.

Default value for Speed Sensor is Enable.

Speed Sensor Resolution

By connecting the TMU-1 to a speed sensor on the motor it is possible to share actual measured speed on the S-Link bus. Either for displaying in control panel or for logging in a Voyage Data Recorder system. Since different speed sensors have different number of pulses per revolution, the resolution must be configured in TMU-1 for each installed instance. Typical Speed Sensor Resolution for sensors on AC thrusters is 1024.

Speed Sensor Resolution	Description
Pulse per revolution	Configure by inputting a number in the range 1 to 5000

Default value for Speed Sensor Resolution is 1024.

Speed Sensor Resolution for applicable thruster models delivered by Sleipner is listed in below table. Consult your documentation to identify correct thruster model.

Thruster model	Pulses per revolution	Motor brand
SHx/x-BA32-S	38	Rexroth
SHx/x-BA40-S	35	Parker
SHx/x-BA45-S	47	Rexroth
SHx/x-BA56-S	47	Rexroth
SHx/x-BA60-S	35	Parker
SHx/x-BA80-S	35	Parker
SHx/x-BA90-S	35	Parker
SHx/x-BA110-S	35	Parker
SHx/x-BA125-S	35	Parker
SHx/x-BA150-S	40	Parker
SHx/x-BA160-S	67	Rexroth
SHx/x-BA180-S	67	Rexroth
SACx/x-x-x-x	1024	Sleipner

Speed Sensor Direction

This parameter is used to swap the sign of the reported RPM.

Speed Sensor Direction	Description
Normal	Sign of reported RPM follows sensor reading. Should be used if starboard direction results in positive RPM readings and negative RPM readings for port direction.
Swapped	Swap the sign of the reported RPM. Should be used if the Normal setting does not give positive RPM readings for starboard direction and negative RPM readings for port direction.

Default value for Speed Sensor Direction is Normal.

Fault situations in S-Link compliant products generates Fault Codes which are broadcasted on the S-Link bus. If a control panel receives a Fault Code, it will trigger an alarm in the control panel and the user will be able to get information about which product that reports the fault and the reason for the fault. Please see the user manual of your S-Link compliant control panel for more information on how to access Fault Code information in case of an alarm situation.

All Sleipner S-Link compliant products have product specific Fault Codes. For legacy reasons some control panels display Generic Fault Codes for certain products.

TMU-1 Fault Codes

Fault Code	Fault Name	Fault Description	Action
10103.0.10	Gearleg Oil - Level Low	Gearleg oil level is low	-Check level indicator on the external oil tank. If low oil level in tank, refill oil and check gearleg for leakage. -If oil level is ok, check that cable between TMU-1 and oil tank sensor is connected and not damaged.
10104.0.212	Motor Speed - Overspeed	Motor speed higher than 5.000 RPM	-Verify that Pulse Per Revolution configuration on TMU-1 matches RPM sensor specification. -Check that cable between TMU-1 and RPM sensor is connected and not damaged.

Responsibility of the Installer

MC_0038

The installer must read this document to ensure necessary familiarity with the product before installation.

Instructions in this document cannot be guaranteed to comply with all international and national regulations. It is the responsibility of the installer to follow all applicable international and national regulations when installing Sleipner products.

The recommendations given in this document are guidelines ONLY, and Sleipner strongly recommends that advice is obtained from a person familiar with the particular vessel and applicable regulations.

This document contains general installation instructions intended to support experienced installers. If you are not skilled in this type of work, please contact professional installers for assistance.

If required by local regulation, electrical work must be done by a licensed professional.

Appropriate health and safety procedures must be followed during installation.


Faulty installation of Sleipner products will render all warranties given by Sleipner Motor AS.

Ensure appropriate access to Sleipner products during installation planning for service, inspection and component replacement.

When installing an S-Link™ system connect ONLY original Sleipner S-Link™ products or other authorized control equipment directly to the S-Link™ bus. Connecting non-authorized third-party equipment, it must always be connected through a Sleipner supplied interface product. Any attempt to directly control or connect into the S-Link™ control system without a designated and approved interface will render all warranties and responsibilities of all of the connected Sleipner products. If you are interfacing the S-Link™ bus by agreement with Sleipner through a designated Sleipner supplied interface, you are still required to install at least one original Sleipner control panel to enable efficient troubleshooting if necessary.

MC_0105

1. Screw the box to a solid surface.
2. Connected S-Link SPUR Cable between TMU-1 and a T-connector on the S-Link BACKBONE Cable. See S-Link System Description chapter for detailed information.
3. Connect RPM Sensor Cable between TMU1- and RPM sensor on motor.
4. Connect Oil Level Sensor Cable between TMU-1 and oil tank.
5. Configure TMU-1. See PJC4xx User Manual for configuration instructions.



MG_0492

S-Link is a CAN-based control system used for communication between Sleipner products installed on a vessel. The system uses BACKBONE Cables as a common power and communication bus with separate SPUR Cables to each connected unit. Only one S-Link POWER cable shall be connected to the BACKBONE Cable. Units with low power consumption are powered directly from the S-Link bus.

Main advantages of S-Link system:

- Compact and waterproof plugs.
- BACKBONE and SPUR Cables have different colour coding and keying to ensure correct and easy installation. BACKBONE Cables have blue connectors and SPUR Cables have green connectors.
- Different cable lengths and BACKBONE Extenders make the system scalable and flexible to install.


Installation of S-Link cables:

Select appropriate cables to keep the length of BACKBONE- and SPUR Cables to a minimum. In case of planned installation with total BACKBONE Cable length exceeding 100 meters please consult your local distributor. The S-Link cables should be properly fastened when installed to avoid sharp bend radius, cable chafing and undesired strain on connectors. Locking mechanism on connectors must be fully closed. To ensure long lifetime, cables, T-Connectors and Extenders should not be located so that they are permanently immersed in water or other fluids. It is also recommended to install cables such that water and condensation do not run along the cables and into the connectors.


The POWER Cable should ideally be connected around the middle of the BACKBONE bus to ensure an equal voltage drop at each end of the BACKBONE Cable. The yellow and black wire in the POWER Cable shall be connected to GND and the red wire connected to +12VDC or +24VDC.

To reduce the risk of interference, avoid routing the S-Link cables close to equipment such as radio transmitters, antennas or high voltage cables. The backbone must be terminated at each end with the END Terminator.


SPUR cables can be left unterminated to prepare for the installation of future additional equipment. In such cases, ensure to protect open connectors from water and moisture to avoid corrosion in the connectors.




BACKBONE Cable
Forms the communication and power bus throughout a vessel. Available in different standard lengths.




T-Connector
Used for connection of SPUR or POWER Cable to the BACKBONE Cable. One T-Connector for each connected cable.




SPUR Cable
Used to connect S-Link compliant products to the backbone cable. One SPUR Cable must be used for each connected component, with no exceptions. Recommended to be as short as practically possible. Available in different standard lengths.



BACKBONE Extender
Connects two BACKBONE Cables to extend the length.




POWER Cable
Required in all installations for connection of BACKBONE Cable to a power supply and should be protected with a 2A fuse.



4-Port T-Connector
The 4-PORT T-connector allows multiple SPUR Cables to be connected. The 4-PORT T-connector comes with two sealing caps to protect unused ports.

S-Link installation example



Find your local professional dealer from our certified worldwide network for expert service and support. visit our website www.sleipnergrouper.com/support

Product Spare Parts and Additional Resources

For additional supporting documentation, we advise you to visit our website www.sleipnergrouper.com and find your Sleipner product.

Warranty statement

1. Sleipner Motor AS (The “Warrantor”) warrants that the equipment (parts, materials, and embedded software of products) manufactured by the Warrantor is free from defects in workmanship and materials for purpose for which the equipment is intended and under normal use and maintenance service (the “Warranty”).
2. This Warranty is in effect for two years (Leisure Use) or one year (Commercial and other Non-leisure Use) from the date of delivery/purchase by the end user, with the following exceptions;
 - (a) For demonstration vessels, or vessels kept on the water, the dealer is considered as the end user from 6 months after their launch of the vessel;
 - (b) The warranty period starts no later than 18 months after the first launch of the vessel.
 Please note that the boat manufacturer and dealer must pay particular attention to correct maintenance and service both by the products manuals as well as general good practice for the location the boat is kept in the period the boat is in their care. In cases where the 6 and 18 months grace periods for boat builders and dealers are passed, it is possible to obtain a full warranty upon inspection and approval of the warrantor or such representative.
3. Certain parts, classified as wearable or service parts, are not covered by the warranty. A failure to follow the required maintenance and service work as described in the product manual render all warranty on parts or components directly or indirectly affected by this void. Please also note that for some parts, time is also a factor separately from actual operational hours.
4. This Warranty is transferable and covers the equipment for the specified warranty period.
5. The warranty does not apply to defects or damages caused by faulty installation or hook-up, abuse or misuse of the equipment including exposure to excessive heat, salt or fresh water spray, or water immersion except for equipment specifically designed as waterproof.
6. In case the equipment seems to be defective, the warranty holder (the “Claimant”) must do the following to make a claim:
 - (a) Contact the dealer or service centre where the equipment was purchased and make the claim. Alternatively, the Claimant can make the claim to a dealer or service centre found at www.sleipnergrouper.com. The Claimant must present a detailed written statement of the nature and circumstances of the defect, to the best of the Claimant’s knowledge, including product identification and serial nbr., the date and place of purchase and the name and address of the installer. Proof of purchase date should be included with the claim, to verify that the warranty period has not expired;
 - (b) Make the equipment available for troubleshooting and repair, with direct and workable access, including dismantling of furnishings or similar, if any, either at the premises of the Warrantor or an authorised service representative approved by the Warrantor. Equipment can only be returned to the Warrantor or an authorised service representative for repair following a pre-approval by the Warrantor’s Help Desk and if so, with the Return Authorisation Number visible postage/shipping prepaid and at the expense of the Claimant.
7. Examination and handling of the warranty claim:
 - (a) If upon the Warrantor’s or authorised service Representative’s examination, the defect is determined to result from defective material or workmanship in the warranty period, the equipment will be repaired or replaced at the Warrantor’s option without charge, and returned to the Purchaser at the Warrantor’s expense. If, on the other hand, the claim is determined to result from circumstances such as described in section 4 above or a result of wear and tear exceeding that for which the equipment is intended (e.g. commercial use of equipment intended for leisure use), the costs for the troubleshooting and repair shall be borne by the Claimant;
 - (b) No refund of the purchase price will be granted to the Claimant, unless the Warrantor is unable to remedy the defect after having a reasonable number of opportunities to do so. In the event that attempts to remedy the defect have failed, the Claimant may claim a refund of the purchase price, provided that the Claimant submits a statement in writing from a professional boating equipment supplier that the installation instructions of the Installation and Operation Manual have been complied with and that the defect remains.
8. Warranty service shall be performed only by the Warrantor, or an authorised service representative, and any attempt to remedy the defect by anyone else shall render this warranty void.
9. No other warranty is given beyond those described above, implied or otherwise, including any implied warranty of merchantability, fitness for a particular purpose other than the purpose for which the equipment is intended, and any other obligations on the part of the Warrantor or its employees and representatives.
10. There shall be no responsibility or liability whatsoever on the part of the Warrantor or its employees and representatives based on this Warranty for injury to any person or persons, or damage to property, loss of income or profit, or any other incidental, consequential or resulting damage or cost claimed to have been incurred through the use or sale of the equipment, including any possible failure or malfunction of the equipment or damages arising from collision with other vessels or objects.
11. This warranty gives you specific legal rights, and you may also have other rights which vary from country to country.

Patents

At Sleipner we continually reinvest to develop and offer the latest technology in marine advancements. To see the many unique designs we have patented visit our website www.sleipnergrouper.com/patents


CE Declaration of conformity (DoC)

We, The Manufacturer:	Sleipner Motor AS Arne Svendsens gate 6-8, NO 1612 Fredrikstad, Norway	
With ISO 9001 certificate:	1484-2007-AQ-NOR-NA, issued by DNV-GL	
Declare that the product: Product Description: Thruster Monitoring Unit Model Numbers: TMU-1-SAC Thruster Monitoring Unit for SAC TMU-1-SH Thruster Monitoring Unit for hydraulic motor		
Subject to installation, maintenance and use conforming to their intended purpose ⁷ is in conformity with the provisions of the following EU Directives: <ul style="list-style-type: none"> • Electromagnetic Compatibility (EMC) - Directive 2014/30/EU • Restriction of the Use of certain Hazardous Substances in Electrical and Electronic Equipment (RoHS) - Directive 2011/65/EC 		
The product is designed to meet the standards and criteria outlined in:	EMC	IEC 60533:2015
	RoHS	EN 63000:2018

This declaration of conformity is issued under the exclusive responsibility of the manufacturer.

Fredrikstad, 8th of February 2022

Ronny Skauen, President and CEO



UK Declaration of conformity (DoC)

We, The Manufacturer:	Sleipner Motor AS Arne Svendsens gate 6-8, NO 1612 Fredrikstad, Norway	
With ISO 9001 certificate:	1484-2007-AQ-NOR-NA, issued by DNV-GL	
Declare that the product: Product Description: Thruster Monitoring Unit Model Numbers: TMU-1-SAC Thruster Monitoring Unit for SAC TMU-1-SH Thruster Monitoring Unit for hydraulic motor		
Subject to installation, maintenance and use conforming to their intended purpose, is in conformity with the provisions of the following UK Regulations: <ul style="list-style-type: none"> • Radio Equipment Regulations 2017 • The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations - 2012 		
The product is tested to meet the standards and criteria outlined in:	EMC	IEC 60533:2015
	RoHS	EN 63000:2018

This declaration of conformity is issued under the exclusive responsibility of the manufacturer.

Fredrikstad, 8th of February 2022

Ronny Skauen, President and CEO



Dotted lines for writing notes.

A series of horizontal dotted lines for taking notes, spanning most of the page width and height.

© **Sleipner Group**, All rights reserved
The information given in the document was right at the time it was published. However, Sleipner Group cannot accept liability for any inaccuracies or omissions it may contain. Continuous product improvement may change the product specifications without notice. Therefore, Sleipner Group cannot accept liability for any possible differences between product and document.

Learn more about our products at
www.sleipnergroun.com



SLEIPNER GROUP

P.O. Box 519

N-1612 Fredrikstad

Norway

www.sleipnergroun.com

Made in Norway

